

# THERMADOR

## MAINTENANCE SCHEDULE

Rev - 19-03-24

### Maintenance Schedule:

Your Thermador door must have the following maintenance performed on it:

### General Maintenance – Undertaken every Four Months

- Check garage door operation in both Automatic and Manual Modes.
- Wash down the garage door with potable water and a clean cloth. Do not use harmful chemicals. Do not wash the garage door opener.
- Clean the garage door guide tracks with a cloth dampened with mineral turps or methylated spirits to remove dirt. DO NOT USE GREASE OR OIL ON THE GUIDE TRACKS.
- Steel hinges: (If fitted). Lightly lubricate with an all-purpose machine oil. Also lubricate wheel to axle bearings.

### Servicing:

- Your Thermador Installer must service the door within 12 months of installation.
- Your Thermador Installer must service the door every 2 years after the first service.

If you do notice an issue with your Thermador, call your installer.

Don't try to fix or adjust the door by yourself.

Failure to undertake this servicing will void the warranty.

Distributor:

# THERMADOR

23 Carr Street, Tuakau, 2121

E: [orders@thermador.co.nz](mailto:orders@thermador.co.nz)

W: [www.thermador.co.nz](http://www.thermador.co.nz)